Installation Instructions for PL Sign

2020 INS V1

1. Preparation of Surface

• Brush the surface clean of dust and debris. If necessary, clean with an industrial cleaner.
• Remove any paint or sealant and then allow the surface to dry.
• It is better for adhesion if surfaces are dry.



2. Marking the location

• Using a measurement tape and pencil, mark the demarcation line on the wall - the bottom of the sign shall not be less than 150mm or more than 400mm above the floor level.
• This will be used as a guideline to position the PL Sign onto the wall.



3. Fixing the PL Sign

• Peel backing of the Double Sided Tape.
• Lay a 3mm (1/8 inch) bead in wave pattern over the full length of the PL Sign.
• Keep the adhesive clear of the outside edge.



Adhesive Usage:
Approximately 18 ~ 20 metres per 600 ml sausage.
Adhesive Brand:
Bostik Seal N Flex FC

4. Placing the PL Sign

• Using the marked line as a guide, place the PL Sign onto the wall.
• Repeat Step 1 to 3 for the other locations.
• Use an alcohol wipe to remove any spill over of adhesive or use a hand cutter to remove.
• Allow approximately 24 hours for adhesive to be fully cured.

