Installation Instructions for Surface Applied Hazard Tile - Timber

2020 INS V1

Access Tile
Tactile Systems

1. Preparation of Surface

• Brush the surface clean of dust and debris. If necessary, clean with an industrial cleaner.
• Remove any paint or sealant and then allow the surface to dry.
• It is better for adhesion if surfaces are dry.



2. Marking the designated location

• Using a measurement tape and pencil, mark the designated location - commencing 300mm back from the stairs.
• This will be used as a guideline to position the Surface Applied Hazard Tile



3. Applying Adhesive

• Lay a 3mm (1/8 inch) bead in wave pattern over the full length of the underside of the Hazard Tile.
• Keep the adhesive clear of the outside edge.



Adhesive Usage:
Approximately 18 ~ 20 metres per 600 ml sausage.
Adhesive Brand:
Bostik Seal N Flex FC

4. Placing the Hazard Tiles

• Using the marked line as a guide, set the tile true and square to the surface and press down firmly.



5. Securing the Hazard Tiles

• Tighten the screws firmly using the Battery Operated Hand Drill - this will create a strong, even bond.
• Ensure the screws are flush with the tile.
• Use an alcohol wipe to remove any spill over of adhesive or use a hand cutter to remove.
• Allow approximately 24 hours for adhesive to be fully cured.

